



- 1.) Place the speaker face down (if possible) and remove the back access hatch.
- 2.) Locate the 4 mounting holes for the transformer at the top of the baffle board above the woofer.
- 3.) With the wiring and connector on the transformer pointing to the LEFT, align the mounting holes in the transformer mounting feet with the holes in the baffle board.
- 4.) On each of the 10-24 machine screws provided in the kit, place a lock washer, then a flat washer.
- 5.) Apply a drop of thread locking compound to the threads near the end of each screw. Insert the screws into the mounting holes and tighten securely, taking care not to cross-thread the T-nuts.
- 6.) Feel underneath the left side of the circuit board on the back of the input panel and locate the two input wires with a flat connector in the middle. (If connectors are not present, see Special Instructions below.)
- 7.) Carefully withdraw the connector and unplug the two halves from each other.
- 8.) Unplug the short pigtails from the Voltage Selector wiring harness. These are only required on early production units which did not have connectors pre-installed.
- 9.) Plug the connectors on the end of the Voltage Selector wiring harness into the mating connectors from the input panel.
- 10.) Route the wiring harness around to the left of the woofer and, using the four #6 screws, mount the Voltage Selector board to the left of the transformer within easy reach of the transformer connector. (4 pilot holes are provided for this purpose but may be obscured by finish overspray.)
- 11.) Secure wiring harness to baffle above and below the woofer on the left side using the cable ties and self-tapping #8 screws.
- 12.) Plug the transformer connector onto the desired voltage header, taking care to align all 8 pins.
- 13.) Apply the "Transformer Equipped" label over the 8 ohm wattage listings on the Input Panel and mark the corresponding box for the selected voltage.
- 14.) Replace the back access hatch and tighten all screws securely and evenly.

Special Instructions for Early Units Without Pre-Installed Connectors

- 1.) Remove Input Panel mounting screws and pull the panel out far enough to gain access to the solder lugs.
- 2.) Unplug the short pigtails from the Voltage Selector wiring harness.
- 3.) Unsolder the BLACK wire from the lug and solder the BLACK wire from the Red/Black pigtail in its place. Do the same with the RED wire.
- 4.) Follow the RED wire you just unsoldered to where it is soldered to the P.C.B. and unsolder it at the board. Solder the GREEN wire from the Green/Black pigtail in its place. Do the same with the remaining BLACK wire.
- 5.) Reinstall the Input Panel in the enclosure.
- 6.) Resume installation of the kit at step 9.



12000 Portland Avenue South, Burnsville, MN 55337
Phone: 952/884-4051, Fax: 952/884-0043
www.electrovoice.com
© Telex Communications, Inc. 9/2003
Part Number 38110-228 Rev A

U.S.A. and Canada only. For customer orders, contact Customer Service at:
800/392-3497 Fax: 800/955-6831

Europe, Africa, and Middle East only. For customer orders, contact Customer Service at:
+ 49 9421-706 0 Fax: + 49 9421-706 265

Other International locations. For customer orders, contact Customer Service at:
+ 1 952 884-4051 Fax: + 1 952 736-4212

For warranty repair or service information, contact the Service Repair department at:
800/685-2606

For technical assistance, contact Technical Support at: **866/78AUDIO**

Specifications subject to change without notice.