# **T**SNet

### **Application Note 4**

### **IRIS-Net™ and Windows Vista OS**

Microsoft Vista is not an officially supported operating system for the installation and operation of IRIS-Net<sup>™</sup> software. However, in most situations, IRIS-Net<sup>™</sup> can be installed and operated on a Vista PC. This document describes a problem caused by installing IRIS-Net<sup>™</sup> on a Vista PC and how to fix the problem for proper operation.

#### Problem

The UCC1 interface is not available in IRIS-Net<sup>™</sup> projects. This can be seen by the following:

- Attempting to add amplifiers to a project. The UCC1 will not appear in the Interfaces list.
- Opening an existing project using a UCC1. The UCC1 will not appear in the project and the connected devices cannot be brought online.
- Adding a UCC1 interface to a project. When dragging a UCC1 into the project, it will not appear in the project screen.

#### Solution

This problem is caused by two installation files not being properly copied into the Windows System32 folder during software installation. These files can be manually copied to the System32 folder to allow IRIS-Net<sup>™</sup> and the UCC1 to operate properly.

- 1. Download and install the IRIS-Net<sup>™</sup> software.
- 2. Close the IRIS-Net<sup>™</sup> software if open.
- 3. Using Windows Explorer, navigate to the PCAN Drive folder in the IRIS-Net<sup>™</sup> software directory. If the software was installed using the default directory path, the files needed are found here: C:\Program Files\EVI Audio\IRIS-Net\Driver\PEAKCAN
- 4. Locate and copy the following files (see Picture 1): CanApi2.dll Pcan2.cpl

					- 🗆 <mark>- X -</mark>
🚱 🕞 🗕 🕌 « EVI Audio 🔸 IRIS-N	Net > Driver > PEAKCAN		✓ <sup>4</sup> → Search		P
🧤 Organize 👻 🏢 Views 👻 🔮	Burn				
Favorite Links	Name	Date modified	Туре	Size	
Documents	🚳 CanApi2.dll	11/26/2003 1:43 AM	Application Extens	60 KB	
	Setcfg32	6/26/2001 2:20 AM	Application	547 KB	
Pictures Pictures	Second Pcan2.cpl	6/25/2004 12:04 AM	Control Panel Item	232 KB	
Music	Pcan_pci	6/15/2005 12:03 PM	Setup Information	3 KB	
More »	🚳 pcan_pci.sys	6/15/2005 9:33 AM	System File	243 KB	
Folders 🗸	Pcan_usb	5/23/2001 12:21 PM	Setup Information	3 KB	
	PCAN_USB.sys	3/1/2003 1:42 AM	System File	197 KB	
earthlink totalaccess	🚔 PcanStat	11/24/2000 2:06 AM	Application	410 KB	
Electrovoice	PcanView.cnt	8/25/2000 11:39 AM	CNT File	1 KB	
Electrovorce	A PcanView	7/5/2001 3:23 PM	Application	697 KB	
	PcanView	11/29/2000 2:51 PM	Help File	175 KB	
Pitmans	PEAKI	2/27/2003 3:49 PM	<b>Registration Entries</b>	1 KB	
Controls	PEAKII	2/27/2003 4:02 PM	<b>Registration Entries</b>	1 KB	
Devices					
Dialogr					
Dialogs +					
13 items					1

Picture 1: Copy files from IRIS-Net folder



## **I**SNet

- 5. Using Windows Explorer, navigate to the Windows System32 folder. It can be found here: C:\Windows\System32
- 6. Paste the two files copied from the IRIS-Net<sup>™</sup> driver directory into the folder (see Picture 2).



Picture 2: Paste files in System32 folder

- 7. Close Windows explorer.
- 8. Launch IRIS-Net<sup>™</sup> and proceed to create or open a project as normal.

