



Tools Required

1. #2 Phillips Screwdriver
2. 3/16in (5mm) Flat Blade Screwdriver

Instructions

The EVU-CDNL4 cover plate is connected to the 4-pin Phoenix Contact connector on the back of the loudspeaker.

To **connect the EVU-CDNL4 cover plate to the loudspeaker**, do the following:

1. Remove the **EVU-CDNL4 cover plate** from the box.
2. Remove the **4-pin connector** from the input cup.
3. Remove and discard the **six (6) screws** from the input panel on the loudspeaker.
4. Secure the **black wire (COM)** to the negative (-) terminal of the connector
5. Secure the **white wire (+)** to the positive (+) terminal of the connector.
6. Tighten all **remaining screws** of the connector to ensure they do not rattle during use.
7. Reinstall the **connector** into the pins on the input cup.

NOTE: The connector can only be installed in one (1) direction.

8. Align the **NL4 cover plate holes** to the input cup holes.

NOTE: Ensure the excess wires do not interfere between the cover plate input cup cover.

9. Using the six (6) pan head screws (included in the kit), attach the **cover plate**.

NOTE: Pin 1 and pin 2 of the NL4 are paralleled to facilitate daisy chaining additional loudspeakers.

Electro-Voice

12000 Portland Avenue South
Bunsville, MN 55337
Phone: (952) 884-4051 Fax: (952) 884-0043
www.electrovoice.com
Bosch Communications Systems
F01U239359 Rev 02
5/2011

For U.S.A and Canada only. Customer orders, contact
Customer Service Phone: **(800) 392-3497** Fax: **(800) 955-6831**
Europe, Africa and Middle East only. For customer orders contact
Customer Service Phone: **+49 9421-706 0** Fax: **+1 (952) 887-9212**
Other International locations. For warranty repair or service information, contact
Service Repair: **(800) 685-2602**
For technical assistance, contact
Technical Support Phone: **(866) 78AUDIO**