

## ORDER No. 19759000

PN 802060

## INSTRUCTION MANUAL

## DESCRIPTION

This antenna has been designed to be used when the telescoping whip supplied with the AAT-2 will not produce a satisfactory signal. This can occur when the AAT-2 is placed in a location that isn't line of sight to the AAR receivers. An example would be a rack mounted AAT-2 in the wings of the stage.


## INSTALLATION

Hang the 1/2-wave coax antenna where it has a clear line of sight to the receiver locations. In the example mentioned earlier, a good location would be behind a non-metallic curtain or set on the stage. Try to keep the antenna at least 4 feet from any wall or metallic object. The antenna may be hung on a wall but performance will be degraded. **DO NOT HANG THE ANTENNA BEHIND A SOLID WALL OR METALLIC OBJECT.** 

The section of the antenna from the "eye" to the larger "junction box" must be vertical - this is the active portion of the antenna.

The remainder of the cable may be routed as necessary to the AAT-2.

Attach the connector on the cable to the jack on the back of the AAT-2. The installation is now complete.



1/2-Wave Vertical Antenna