**Electro-Voice** | RE3-HHTNID-T Handheld TX with no head, 803-806MHz

# RE3-HHTNID-T Handheld TX with no head, 803-806MHz

- Robust metal body
- 3 MHz tuning bandwidth
- Selectable 10mW and 50mW output power
- Common threaded coupling allows microphone head interchangeable
- Sync function for easy frequency setup




## Technical specifications

Frequency oscillation mode:	Phase-locked loop (PLL)
Band name:	Т
Tuning bandwidth:	3 MHz
Frequency range:	803-806 MHz
Sync frequency:	Ultrasonic
RF power output:	Low 10mW / High 50mW
Display by:	LCD + LED
Function controls:	Power, mute, group, channel, frequency, sensitivity adjustment, RF power, auto off, key lock.
RF stability:	<±10kHz@Fc
Modulation frequency shift:	Wideband FM ±48kHz deviation
Harmonic radiation:	<-50dBc
Battery:	2 x AA alkaline battery or NiMH rechargeable battery
Charging contacts:	Yes

Microphone coupling:	1.25" diameter, 28 UN-2A thread pitch
Microphone electrical contact:	3-ring/3-pin
Finish:	Black polyurethane paint
Dimensions (without head):	Height: 7.52 in. (191mm) Width at threaded end: 1.46 in. (37mm) Width at control cover: 0.856 in. (22mm)
Net weight: (without head):	12.2 oz. (346 g)
Gross weight (without head):	16.9 oz. (480 g)



#### **Dimensions:**



For full operational information, download the RE3 installation manual at www.electrovoice.com.

#### Notices

#### **Battery precautions**

- Keep batteries out of the reach of children.
- Observe and install batteries according to the correct polarity as marked on the battery and the transmitter battery compartment.
- Do not expose the battery to excessive heat such as sunshine, fire, or other sources of high heat.
- Always consider the environment issues and follow local regulations when disposing of batteries.
- Remove depleted battery immediately.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Use only disposable LR6 (AA) alkaline or NiMH batteries.
- Do not mix new batteries with old ones in the transmitter at the same time.
- Do not use different battery types or models.
- Do not use a leaking battery. If battery leakage occurs, avoid contact with skin. If contact occurs, immediately wash thoroughly with soap and water.
- If battery leakage comes into contact with your eyes, immediately flush with water and seek medical attention.

• Remove and safely store batteries away from the transmitter when the transmitter will not be used for 60 or more days.

#### **Replacement parts**

Order number	Description
ESP-EF01U362339	RE3-HHT bottom section with slide door
ESP-EF01U362340	RE3-HHT display window
RE3-ACC-HHTSA1	Stand adapter for RE3-HHT transmitter

#### **Compatible products**

Order number	Description
ND76-RC3	Wireless head with ND76 capsule
ND86-RC3	Wireless head with ND86 capsule
ND96-RC3	Wireless head with ND96 capsule
RE420-RC3	Wireless head with RE420 capsule
RE520-RC3	Wireless head with RE520 capsule

### **Parts included**

Quantity	Component
1	Handheld transmitter with stand adapter
2	AA batteries
1	Engineering datasheet
1	Warranty and product documentation information card

## **Ordering information**

**RE3-HHTNID-T Handheld TX with no head, 803-806MHz** Not available for sale individually. Order number **RE3-HHTNID-T** 

Represented by:

Germany: Bosch Sicherheitssysteme GmbH Robert-Bosch-Ring 5 85630 Grasbrunn Germany

www.electrovoice.com

Bosch Security Systems, Inc. 12000 Portland Avenue South Burnsville MN 55337 USA

© Bosch Security Systems 2019 | Data subject to change without notice Document Number F.01U.364.271 | Vs1 | 11. Jan 2019