

Electro7/oice®

S-40MB Mounting Bracket Kit

WALL MOUNTING INSTRUCTIONS

- 1. Refer to Figure 1 for the following steps.
- Remove the paper backing from one of the Friction Pads (C) and attach to the U-Bracket (A) as shown. Be sure the two 1/4-inch holes are aligned. Attach the second Friction Pad in a similar manner.
- Attach the U-Bracket to the wall using fasteners that are suitable for the wall material (not supplied).
- Remove the two plastic hole plugs from each end of the S-40 or S-40T speaker by gently prying with a small screwdriver.
- Place a Nylon Washer (D) on the threaded stud of each of the Torque Knobs (B).
- Mount the S-40 or S-40T speaker to the U-Bracket using the Torque Knobs and Nylon Washers. Do not tighten.
- Rotate the speaker so that the input panel is accessible and attach the wires to the input panel. Position the speaker for the desired coverage and gently tighten the Torque Knobs.

MICROPHONE STAND MOUNTING INSTRUCTIONS

- 1. Refer to Figure 2 for the following steps.
- Remove the paper backing from one of the Friction Pads (C) and attach to the U-Bracket (A) as shown. Be sure the two 1/4-inch holes are aligned. Attach the second Friction Pad in a similar manner.
- Screw the U-Bracket assembly onto the mic stand using the threaded middle hole on the U-Bracket.
- Snug the mic stand locking nut on the bottom side of the bracket to prevent it from moving.
- Remove the two plastic hole plugs from each end of the S-40 speaker by gently prying with a small screwdriver.
- Place a Nylon Washer (D) on the threaded stud of each of the Torque Knobs (B).
- Mount the S-40 speaker to the U-Bracket using the Torque Knobs and Nylon Washers. Do not tighten.
- Rotate the speaker so that the input panel is accessible and attach the wires to the input panel. Position the speaker for the desired coverage and gently tighten the Torque Knobs.

ltem	Quantity	Description
А	1	U-Bracket
В	2	Torque Knob
С	2	Friction Pad
D	2	Nylon Washer



WARRANTY (Limited)

Electro-Voice products are guaranteed against malfunction due to defects in materials or workmanship for a specified period, as noted in the individual product-line statement(s) below, or in the individual product data sheet or owner's manual, beginning with the date of original purchase. If such malfunction occurs during the specified period, the product will be repaired or replaced (at our option) without charge. The product will be returned to the customer prepaid. Exclusions and Limitations: The Limited Warranty does not apply to: (a) exterior finish or appearance; (b) certain specific items described in the individual product-line statement(s) below, or in the individual product data sheet or owner's manual; (c) malfunction resulting from use or operation of the product other than as specified in the product data sheet or owner's manual; (d) malfunction resulting from misuse or abuse of the product; or (e) malfunction occurring at any time after repairs have been made to the product by anyone other than Electro-Voice or any of its authorized service representatives. Obtaining Warranty Service: To obtain warranty service, a customer must deliver the product, prepaid, to Electro-Voice or any of its authorized service representatives together with proof of purchase of the product in the form of a bill of sale or receipted invoice. A list of authorized service representatives is available from Electro-Voice at 600 Cecil Street, Buchanan, MI 49107 (616/695-6831) and/or Electro-Voice West, at 8234 Doe Avenue, Visalia, CA 93291 (209/651-7777). Incidental and Consequential Damages Excluded: Product repair or replacement and return to the customer are the only remedies provided to the customer. Electro-Voice shall not be liable for any incidental or consequential damages including, without limitation, injury to persons or property or loss of use. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you. Other Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Electro-Voice Accessories are guaranteed against malfunction due to defects in materials or workmanship for a period of one (1) year from the date of original purchase. Additional details are included in the Uniform Limited Warranty statement.

Service and repair address for this product: Electro-Voice, Inc., 600 Cecil Street, Buchanan, Michigan 49107.

Specifications subject to change without notice.

