60 Watt Transformer Kit for 70.7/100 Volt Lines EVU Loudspeaker Systems Installation Instructions



High Pass Filter Requirements

The EVU-TK60 transformer is used with a 90Hz Butterworth 24dB/octave active high-pass filter inserted in the signal chain at the input to the driving amplifier. This filter protects the amplifier from damage caused by transformer saturation at low frequencies and allows any number of transformers to be driven on the same line, up to the rated power of the amplifier.

CAUTION: Failure to use the proper high-pass filter may result in damage to the amplifier.

Tools Required

- #2 Phillips Screwdriver
- 3/16" (5mm) Flat Blade Screwdriver

Instructions

The EVU-TK60 transformer is connected to the 4-pin Phoenix Contact connector on the back of the loudspeaker.

To install the EVU-TK60 transformer, do the following:

- 1. Remove the **EVU-TK60 transformer** from the box.
- 2. Remove the **4-pin connector** from the input cup.
- 3. Remove and set aside the six (6) screws from the input panel on the loudspeaker.
- 4. Secure the **blue wire** (COM) to the negative (-) terminal of the connector.
- 5. Secure the **yellow wire** (+) to the positive (+) terminal of the connector.
- 6. Tighten all **remaining screws** on the connector to ensure they do not rattle during operation.
- 7. Reinstall the **connector** into the pins to the input cup.

NOTE: The connector can only be installed in one (1) direction.

8. Align the EVU-TK60 transformer holes to the input cup holes.

NOTE: Ensure the excess wires do not interfere between the cover and input cup.

- 9. Using the six (6) screws from in Step 3, attach the EVU-TK60 transformer.
- **CAUTION:** This transformer affects only the loudspeaker to which it is installed. Improper connection may result in damage to the transformer, successive loudspeakers, the driving amplifier or any combination of these units.
- **NOTE:** To **daisy chain additional systems**, connect one (1) wire only to each free positive (+) and negative (-) on the outside of the EVU-TK60 transformer connector.

Electro-Voice

12000 Portland Avenue South Bunsville, MN 55337 Phone: (952) 884-4051 Fax: (952) 884-0043 www.electrovoice.com Bosch Communications Systems F01U239358 Rev 03 6/2011 For U.S.A and Canada only. Customer orders, contact Customer Service Phone: (800 392-3497 Fax: (800) 955-6831 Europe, Africa and Middle East only. Customer orders, contact Customer Service Phone: +49 9421-706 0 Fax: +1 (952) 887-9212 Other International locations. For warranty repair or service information, contact Service Repair: (800) 685-2602 For technical assistance, contact Technical Support Phone: (866) 78AUDIO